



ANALOG SIGNAL PODS ARE POWERFUL, BRIGHT, AND HIGH QUALITY.

SPECS

- Pod Size: 1.45" (36.8mm) x .73" (18.5mm) x .55" (14mm)
- LED: Two per signal, Flip Chip C3535 3W
- Power Draw: 6 Watts per signal (12 watt pair)
- Amber in color with built in voltage regulator
- Input Voltage: 12V DC
- Designed for flat surface mounting
- For off road use only
- Waterproof

INCLUDES

- 1 pair of Analog Signal Pods
- Directions for bike specific install (if applicable)
- (x4) Posi-Lock Connectors, PL1824 18-24 AWG
- (x2) M5x20 Set Screw, DIN 913
- (x2) M5 Nylock Nut DIN 985

DIRECTIONS (for universal mounting):

- Locate where you want to mount the pods.
- Drill 2 holes .66" (16.7mm) apart (.20" (5mm) hole for bolt and .25" (6mm) hole for wires).
- Locate your bikes turn signal wires and determine which wire is positive and which wire is negative.
- Using the Posi Tap wiring connectors tap the signal pods Black wire into your bikes negative and signal pods White wire into your bikes positive on your bikes left or rights respective side.
- For turn signal use only.

Post a picture and tag us after installing:
@analogmotorcycles + @analogmotorgoods

