

Denali Horn Mount

BMW G650GS 2009-2015
BMW F650GS Single 2000-2007

HMT.07.10200 Instructions Rev:01

PLEASE READ BEFORE INSTALLING

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.

All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....	3.5 ft-lbs (5 Nm)
M6.....	7 ft-lbs (9.6 Nm)
M8.....	13 ft-lbs (18 Nm)

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

Distributed by:

Twisted Throttle LLC
 570 Nooseneck Hill Rd
 Exeter, RI 02822

phone: 855.255.5550
 fax: 401.223.6955
 www.twistedthrottle.com

Installation Instructions



Step One: Remove the OEM upper frame bolt from the motorcycle. Use the M8 bolt (#2) included with the kit to replace the OEM bolt and attach the bracket (#1). Mount the horn to the bracket.

