



**Kit # 2711(Y)-TS, 3212(Y)-TS, 4014(Y)-TS
Installation Instructions**

This LED light kit comes with super-bright amber LED arrays for forward-facing use and is designed to be mounted on handguards, mirrors and other locations on the front of a motorcycle or scooter. This LED light kit can be connected to operate in one of the following ways:

| Option* | Operation | LED Array wires |
|---------|---|--|
| # 1 | Super bright Running lights (no turn signals) | Connect red wire to switched +12v (e.g. headlight wire), black to ground. Repeat on other side with second LED array. |
| # 2 | Super bright Turn signals (no running lights) | Connect red wire to turn signal wire, black to ground. Repeat on other side with second LED array. |
| # 3 | Bright Running lights with turn signals | Connect red wire to yellow wire of mini controller. Connect Blue wire to switched +12v (e.g. headlight wire), Red wire to turn signal wire, black to ground. Repeat on other side with second LED array. |

*Note: Included mini controllers are not required for Installation Options # 1 & # 2.

Test the proper functioning of your LED light kit. Ensure that all wires are properly secured and do not interfere with operation of your motorcycle or scooter including steering, brake and suspension functions.