

Denali Horn Mount

Honda NC700X '12-'14

HMT.01.10000 Instructions Rev:00

PLEASE READ BEFORE INSTALLING

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.

All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....	3.5 ft-lbs (5 Nm)
M6.....	7 ft-lbs (9.6 Nm)
M8.....	13 ft-lbs (18 Nm)

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.


Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

Distributed by:	
Twisted Throttle LLC 570 Nooseneck Hill Rd Exeter, RI 02822	phone: 855.255.5550 fax: 401.223.6955 www.twistedthrottle.com



Installation Instructions

1
Mounting Bracket




HMT.01.001
Qty.....1

2
Hex Head Bolt



M6x35.....DIN 6921
Qty.....2

3
Washer



M6.....DIN 125
Qty.....2

Step One: Remove the two OEM bolt from the right side engine case as illustrated above. Use the bolts (#2) and washers (#3) to bolt the bracket (#1) to the motorcycle. Bolt the horn to the mounting bracket using the hardware that was supplied with the horn.

