

RAM X-Grip® Tether Instructions (Optional)

Recommended for heavy duty or outdoor open cockpit use.
Size of tether may vary depending on size of your X-Grip®

Insert center of tether over ball or adapter behind X-Grip®. While X-Grip® is holding device, wrap corners of tether over the front side of device.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RAM X-Grip® Tether Instructions (Optional)

Recommended for heavy duty or outdoor open cockpit use.
Size of tether may vary depending on size of your X-Grip®

Insert center of tether over ball or adapter behind X-Grip®. While X-Grip® is holding device, wrap corners of tether over the front side of device.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RAM X-Grip® Tether Instructions (Optional)

Recommended for heavy duty or outdoor open cockpit use.
Size of tether may vary depending on size of your X-Grip®

Insert center of tether over ball or adapter behind X-Grip®. While X-Grip® is holding device, wrap corners of tether over the front side of device.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RAM X-Grip® Tether Instructions (Optional)

Recommended for heavy duty or outdoor open cockpit use.
Size of tether may vary depending on size of your X-Grip®

Insert center of tether over ball or adapter behind X-Grip®. While X-Grip® is holding device, wrap corners of tether over the front side of device.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com

